

Extreme Duty Adjustable Clutch Rod, 66-77 Bronco

1. Install left hand thread offset clevis on rod.
2. Attach clutch rod boot (not included).
3. Put rod with boot through hole in floor pan.
4. Using the clevis pin and bushing install on clutch pedal and secure with cotter pin.
5. Position boot in floor.
6. Add right hand jam nut and rod end to lower end of rod.
7. Bolt rod end to bell crank/equalizer bar as shown.
8. Once this is adjusted and tested you can tighten lower jam nut against rod end and retest for proper function.

