

Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

Heat Blaster Kit

#5206 Date 10/12/11

Parts list: Motor Fan 2 electric connectors Six screws

- 1. Disconnect battery just to be safe.
- 2. Remove heater from Bronco.
- 3. Remove stock motor and fan.
- 4. Position new motor with flat portion against the passenger side of the heater box. It will match the flat part of the box.
- 5. Mark the heater box to drill six holes for screws to hold the new motor into the heater box. Pic #1
- 6. Center the fan and mark the heater box for cutting to make clearance for the new fan. You will be cutting more towards the passenger side of the box. Pic#2
- 7. Drill holes and trim box to fit fan.
- 8. Attach fan to motor and test fit.
- 9. Install motor and fan to heater box using six screws.
- 10. Use ground wire from old motor. Attach ground wire from metal dash to one of the screws used to hold motor to the heater box.
- 11. Attach hot wire to motor using connector.
- 12. Connect battery and check motor operation.
- 13. Install heater into Bronco.



