

WILD HORSES

FOUR WHEEL DRIVE

Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

Racket Jacket Top Kit

#3483 Date 11/08/05 rev. 0

Kit Contents:

6 - Sound dampener pads (3 for half cab)
3-Pre-Trimmed Heat Absorber/Barrier Panels
(1 for half cab)
1-Spray Adhesive

Tools Needed for Installation:

* Sharp knife or scissors
* Wallpaper seam roller

Installation of any Racket Jacket product begins with preparation of the interior metal surfaces. All panels must be thoroughly cleaned, washed and painted (recommended). Over time, adhesive material will not stick to dusty, dirty, grimy body panel surfaces. They must be bone dry and be sure that the temperature of metal surface is above 70 degrees.

Installation: Lay out the sound damper pads centered in each of the three large areas of the top. When you are satisfied that all the damper pads are in their correct location, remove the protective film from each pad, exposing the self-adhesive surface, and “lightly tack” the pad in place. Use the wallpaper seam roller to pressure roll the damper pads to the metal skin of the top, removing all air gaps so that the adhesive backing firmly grips the metal. Work the roller across the damper material from the center toward the edge.

2. Applying the heat absorber/barrier photo 1 (full top) or photo 2 (half cab) shows the approximate size and shape of the pre-trimmed, ready-to-install heat absorber/barrier panels and the location they will be installed in the roof. Lay the panels into the roof, aluminum side facing in as shown, smoothing the material out as you go. Some “nipping” of the edges with the scissors may be required. Spray glue the fibrous side of an absorber panel and set it aside to dry. Spray glue the corresponding section of the roof to which this panel will be applied. Now STOP and let everything become tacky. This is the key to permanent adhesion. When the glued surface is “tacky to touch” it is ready to be installed.

