



Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

INSTRUCTIONS FOR #6086 and #6129

1. Disconnect the battery for safety.
2. Unplug the headlight connectors from headlight bulbs.
3. Plug in the removed female headlight connector on the passenger side into the male connector of the new harness.
4. Plug the new headlight connectors onto the headlight bulbs. Route to drivers side first.
Ground the black ground wire to the core support.
5. Mount relays in an appropriate location on the core support above the passenger headlight.
6. Route the red wires to a battery source.
7. The old driver's side headlight connector will not be used, it can be taped up.
8. Reconnect battery.
9. Turn on headlight and check if they operate correctly.

For best performance we recommend the use of dielectric grease on all electronic connectors