

# WILD HORSES

FOUR WHEEL DRIVE

Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

## Rear Inboard Shock Hoop

#1410 Date 10/19/07

**Parts list:** 1 - Rear Hoop 2 - 1/2" x 4 1/2" GR8  
2 - 1/2" x 2 1/2" GR8 10 - 1/2" flat washers  
4 - 1/2" GR8 NY lock nuts

Please note this is a weld-on unit. Also, these are recommended locations. Special applications may need slightly different locations.

1. The upper hoop slides in-between the frame rails directly above the axle housing. (use bump stop mounting area as a reference).
2. Side plates should be flush with the bottom of the frame rail. There should be approximately 1/4-1/3" between hoop and floor board.
3. The lower mount should locate approximately 4" from the inside edge of the spring perch to center of new lower shock mount. (use two washers in-between the lower shock mount and shock).
4. Check and retighten all hardware periodically and after each off road excursion.

