



Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

Rear Bump Stop Mounting Bracket

#1561 Date 10/30/07

Parts list:

2 - rear bump stop
mounting brackets

Hardware list:

4 - 5/16-18x3/4" Flat Head Allen Screws
4 - 5/16-18" NC Nylock Nuts
4 - 5/16" Flat Washers
1 - Instructions

Suggested Tools:

1 - 3/16" Allen Wrench
2 - Ratchet Driver
3 - 1/2" Socket

1. Remove the factory bump stops by removing the two 5/16" bolts that secure the bump stop to the frame.
2. Using the supplied 5/16" tapered bolts, install the mounting plates to the frame. Make sure that the mounting plate sits flat on the frame.
3. Install the new bump stops to the mounting bracket using the supplied nuts and washers.