



Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

Steering Stabilizer Brackets

#2429 Date 8/31/06

Parts List: 1 – frame bracket
1 – draglink bracket
1 – hardware kit

Tools list: ½” socket and wrench

1. Install the draglink bracket on the draglink. If installing on a stock draglink, the u-bolts will install on either side of the metal tab welded on the steering box end. If the draglink is not stock, position the bracket close to the pitman without interfering with its operation. Note the position of the mount eye. See Figure 1.
2. Install the frame bracket to the frame cross member. Normally there will be two mounting holes located on the cross member close to the passenger side. Note the position of the mount eye. See Figure 1.

