



Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

Racket Jacket Door Kit

#3485 Date 11/08/05 rev. 0

Kit Contents:

6 - Sound dampener pads

Tools Needed for Installation:

- * Sharp knife or scissors
- * Wallpaper seam roller

Installation of any Racket Jacket product begins with preparation of the interior metal surfaces. All panels must be thoroughly cleaned, washed and painted (recommended). Over time, adhesive material will not stick to dusty, dirty, grimy body panel surfaces. They must be bone dry and be sure that the temperature of metal surface is above 70 degrees.

Installation: Apply the sound dampener pads to the large flat section of the Bronco door.

Three pads should be applied evenly spaced across the door panel skin (three pads per door). Strips can be placed horizontally or vertically on the door skin. You can cut the pads if it helps for installation.

“Pressure roll” the damper pads to the metal skin of the door so that all air gaps are removed ensuring that the adhesive backing firmly grips the metal skin.

Use a wallpaper seam roller because it easily rolls in narrow paths and you can apply hard pressure with it. Work the seam roller along the damper pad from the center toward each end.

