

WILD HORSES **FOUR WHEEL DRIVE!!!**

Phone (209) 400-7200W Fax (209) 943-7923 www.wildhorses4x4.com

Diamond Plate Rocker Covers

#5711 Date 08/12/04 rev. 1

Parts

2 ea. Diamond rocker covers

Hardware

24 ea. 10x1" sheet metal screws

Suggested tools

1. Cut off wheel, jig saw or grinder
2. Drill
3. 7/64" drill bit
4. File or grinder

These are our cut-to-fit Diamond Plate Rocker Covers. For years all that was available were covers that were 4' long, which was not long enough for all the different flare combinations that we have seen. When we designed our Rocker Panel Covers we made sure that they could be trimmed to fit any style or brand of flare you have on your Bronco.

1. Remove the bottom few pop rivets (or screws) attaching the flare to the body.
2. Gently pull the flare from the body and slide the Diamond Plate Rocker Cover under the flare.
3. While holding the Diamond Plate Rocker Cover on to the rocker panel, scribe the contour of the flare(s) on to the Diamond Plate Rocker Cover.
4. Carefully remove the Diamond Plate Rocker Cover and trim as necessary using a cut off wheel, jigsaw, or grinder.
5. File the edges to remove the burrs.
6. Reattach the flare using pop rivets or screws.
7. Position the Diamond Plate Rocker Cover and secure it with the provided sheet metal screws.

