

# WILD HORSES

FOUR WHEEL DRIVE

Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

## Tailgate Cables #5778 Date 12/01/12

**Parts list:** 2 - Cables 2 - Allen bolts  
2 - Spacers 2 - inserts

1. Remove old tailgate support on driver side. This way the other side can support the tailgate while you work.
2. Slide the tailgate cable over the support attachment on the tailgate as shown in pic#1 (pic#1 shows driver side)
3. Install the insert into the cable. The spacer will be against the body. Slide allen bolt through. Slide your allen wrench through the hole in the tailgate striker to tighten down the bolt. (pic#2) (pic#3)
4. Check operation with this one side installed.
5. Now you can remove the other side tailgate support and install cable just like the first one.

NOTE: cables are offset for clearance install cable with offset as shown in pics. Pics are all driver side. Passenger side will be a mirror image.

