



Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

Split Braided Wire Sleeve Kit

#6091 Date 04/01/09 rev. 0

- 6 ft. - 3/4 inch Split Braided Wire Sleeve
- 23 ft. - 1/2 inch Split Braided Wire Sleeve
- 40 ft. - 1/4 inch Split Braided Wire Sleeve
- 38 ft. - 1/8 inch Split Braided Wire Sleeve
- 7" zip ties
- 4" zip ties
- 1 ft. - 1/2 inch heat shrink tubing
- 2 ft. - 3/8 inch heat shrink tubing
- 2.5 ft. - 1/4 inch heat shrink tubing
- 1 roll electrical tape
- 1 roll self vulcanizing tape

Before installation of the Split Braided Wire Sleeve on the harness, be sure to have all sections of the harness going to their specific locations. This will help you to determine what size sleeve to use in any specific area.

After laying out the harness take the time to replace all existing zip ties with the black electrical tape that is supplied in the Split Braided Wire Sleeve kit. This step is optional but it will make the installation of the sleeve much easier.

Using the correct diameter for each wire section, install the Split Braided Wire Sleeve. When finished with each section, cut any extra length of sleeve with a sharp pair of scissors and then secure it using the supplied self vulcanizing tape to wrap the ends. This will keep the Split Braided Wire Sleeve from fraying. On ends that do not have connectors, the heat shrink can be used to seal ends instead of the tape.