



Phone (209) 400-7200 Fax (209) 943-7923 [www.wildhorses4x4.com](http://www.wildhorses4x4.com)

## After Burners & Side Burns

#799386 Date 4/28/09

**Parts list:**

1 Right After Burner  
1 Left After Burner  
Optional 2R 2L Side Burners

**Hardware list:**

2 - 10 x 3/4" screws  
4 - 10 x 1 3/4" screws  
Hardware is for After Burners only

1. After Burners can be installed without removing the taillight lens from the vehicle. Remove the top screw which holds the taillight lens to the vehicle.
2. Position After Burner on lens and install the screw you removed in step 1.
3. Use 5/32 drill bit and drill lower screw hole in taillight lens.
4. Use 10 x 3/4" screw to hold After Burner to taillight lens. CAUTION do not over tighten or you will damage lens.
5. Install Side Burns (optional) using original side marker light screws.