

Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

Extreme Motor Mounts

#8036 Date 7/15/14

Parts list:

2 - Frame mount
2 - Bolts
2 - Lock nuts
4 - Urethane bushing
2 - lock washers

2 -DOM sleeves 2 - Nuts

Assemble as show in exploded view. DOM sleeve is not shown but goes through the bushings. Use some polyurethane grease on the bushings and sleeve. They are intended to be tight so the use of a large rubber hammer will be helpful when installing the bushings and sleeves.

Some later model 5.0/5.8 will need slight engine mount modifications for clearance.

Bolt mount to motor first to check for any clearancing needs. This will not be necessary for original 66-77 Bronco V-8s.

If you find you need clearance to bolt the mount on the motor a simple 4.5" grinder will do the trick.

