

# ADVANCE ADAPTERS INC.

P.O. Box 247, 4320 Aerotech Center Way  
Paso Robles, CA 93447

Telephone: (800) 350-2223 Fax: (805) 238-4201

P/N: 716050C, 716050D  
716050D1

PAGE 1 OF 1

Page Rev. Date: 06-01-01

## NEW VENTURE SHIFT HANDLES

KIT NO. 716050C (Chevy 1993-99) CONSISTS OF

No.	Qty.	Part No.	Description
1.	1	716050B	SHIFTER HANDLE BASE
2.	1	716050H	SHIFT HANDLE
3.	1	716050K	SHIFT KNOB
4.	1	720061	10mm X 1.5 50mm LG. STUD
5.	1	726203	5/8"-18 HEX JAM NUT



KIT NO. 716050D (Dodge 1993-98) CONSISTS OF:

No.	Qty.	Part No.	Description
1.	1	716050H	SHIFTER HANDLE
2.	1	716050K	SHIFT KNOB
3.	1	716050S	SHIFT HANDLE STUD
4.	1	720061	10mm X 1.5 50mm LG. STUD
5.	1	726203	5/8"-18 HEX JAM NUT



### SPECIAL 716050D NOTES:

1. Remove rubber boot.
2. Remove retaining cup - Push down and turn cup counter clockwise, then pull straight stud out of top cover.
3. Remove old stud by driving 1/4" roll pin out of base.
4. Install Part No. 716050S into base. Reassemble using original 1/4" roll pin.

KIT NO. 716050D1 (Dodge 1999 & Newer) CONSISTS OF:

No.	Qty.	Part No.	Description
1.	1	716050	SHIFTER HANDLE BASE
2.	1	716050H	SHIFT HANDLE
3.	1	716050K	SHIFT KNOB
4.	1	720061	10mm X 1.5 50mm LG. STUD
5.	1	726203	5/8"-18 HEX JAM NUT



**SPECIAL NOTE:** The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.