



Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

## Instructions for Fiberglass Hoods and hood hinges

#5862 Date 7/15/13

### Parts

2 ea. S.S. Hinges

### Hardware

6 ea. 1/4" x 1" Bolt

6 ea. 1/4" Nuts

6 ea. 1/4" Washers

**Please note: WH hoods do not come with hinges. Hinges and other hood components can be purchased separately.**

1. Mount the hood hinges to your new hood. If you are going to use your old hood hinges from the steel hood, you will need to drill the spot welds that hold the hinges to the hood.
2. Position the new hinges on the hood so that they are in the stock location. Drill the holes in the hood and bolt the new hinges onto the hood with the heads of the bolts on the outside of the hood.
3. Even if you are going to paint the hood, you should bolt it all up including installation of hood pins and hood shocks. This way you can fit, sand, and finish the hood as necessary before your final installation.

**NOTE: Original Bronco shims can be used between the back of the hinge and the hinges mounting location on the Bronco for alignment and adjusting purposes.**

**NOTE: Hoods are designed so they can be installed right out of the box; however, if you are after "show quality" you will need to sand and finish which could include body filler as necessary to meet your needs.**

Follow us on social media!



@wildhorses4x4

Look up our video tutorial  
for this product on  
our YouTube channel!

