

Master Cylinder for Hydroboost Date 6/01/17 rev. 0

Do not press the brake pedal without the master cylinder installed correctly on the hydroboost unit. Failure to install the master cylinder correctly will result in blowing out the hydroboost unit. WH will not be responsible for this under any circumstances.



The “bullet” must be installed in the bore of the master cylinder before bolting it up to the hydroboost unit. Without it you will blow up the unit and have to buy another one. Please call if you have any questions.