



## HEI Module Installation Instructions

- \* Street/Strip Modules are Legal in all 50 states and Canada, CARB E.O. #D-57-7
- \* Race Modules are not legal for sale or use on pollution controlled motor vehicles.

1. Disconnect the battery negative (-) cable.
2. Remove the distributor cap and rotor.
3. Disconnect the pickup coil wiring harness from the module.
4. Remove the two module mounting screws.
5. Remove the module from the distributor housing.
6. Clean the distributor housing, and module mounting position.
7. Apply the provided thermal compound to the clean module mounting surface. Spread the compound evenly over the entire area.
8. Install the Flame-Thrower module into the distributor housing. Make sure that the module prongs engage with the wiring harness connector.
9. Use the original mounting screw to secure the Flame-Thrower module in place.
10. Reattach the pickup coil wiring harness to the Flame-Thrower module.
11. Install the rotor and distributor cap.
12. Reconnect the battery negative (-) terminal.