

WILD HORSES

FOUR WHEEL DRIVE

Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

Retractable Lap Belts

#3639 Date 02/07/12 rev. 0

Parts

2 ea. Retractor assemblies
2 ea. Buckle assemblies

Hardware

6 ea. 7/16" x 1 1/2" NF bolts
2 ea. 7/16" NF nuts
6 ea. 7/16" lock washers
2 L-brackets

1. We use the stock seat belt mounting hole to mount the L bracket to the floorboard. Use the 7/16" fine thread bolt to bolt the L bracket to the floor. Do not tighten the bolt completely down at this time, leave it loose enough for the bracket to rotate on the bolt.
2. Use another 7/16" bolt to mount the belt retractor assembly to the L bracket as shown in the photo. The photo shows the normal position of the retractor in relation to the seat. Tighten all L bracket and retractor bolts once you have it in the right position.
3. Mount the buckle to the floor.

